





Coordination of Earth Stations

BR-SSD e-Learning Center

Why ?

Propagation do not care for Borders.



COORDINATION OF EARTH STATIONS



Volume No.1
Article 5



Article 9



Provisions : 9.6, 9.15, 9.17, 9.17A, 9.21



Volume No.2

Appendix 5



Coordination area : Appendix 7



Appendix 4



Coordination data to neighboring countries



(Vol. 1) Article 11



Notification in Master Register

Region 1

5850 - 5925 MHz

FIXED

FIXED-SATELLITE

(Earth-to-space) ↑

MOBILE

All Regions

6700 - 7075 MHz

FIXED

FIXED-SATELLITE

(Earth-to-space) ↑


(space-to-Earth) ↓

MOBILE

When ?


Volume No.1 → **Article 5**

Region 1
5850 - 5925 MHz
FIXED FIXED-SATELLITE <i>(Earth-to-space)</i> ↑



equal rights
Space = Terrestrial

All Regions
6700 - 7075 MHz
FIXED-SATELLITE <i>(Earth-to-space)</i> ↑ <i>(space-to-Earth)</i> ↓



opposite direction
Uplink = Downlink

- If coordination area includes the territory of another country

PROVISIONS for effecting COORDINATION


Article 9



**Space Service
under No. 9.21
agreement**

(ex: footnote 5.461 – MSS)

Why AP7?



AP7

Anomalous (short-term) Interference Propagation mechanisms

Common Volume
at the intersection
of the antenna main beams

Elevated layer
reflection/refraction
($h < x \ 100\text{m}$)

Tropospheric scatter
($>100\text{km}$)

Ducting
($>500\text{km}$)

Diffraction
(local)


Hydrometeor scatter

Great-circle propagation
(Mode 1) – 4 Radio-Clim. zone

+

Hydrometeor scatter
(Mode 2) – 15 Rain zone A-Q

→ Coordination Distance



Simple button?


Computer Program for Determination of Coordination Area

AP7 embedded in GIBC



C:\BR_SOFT\BATCH

Create your Input File



Graphical Interface for Batch Programs

Appendix 8 PFD (terrestrial serv.) PFD (space serv.)
Appendix 7 Appendix 30B Appendix 30 30A Tools / Options

Network ID: 109500000

Warning Error Progress

Message	Module	Code
---------	--------	------

Calculation Output

Aux Contours

Out DB: C:\BR_TEX_RESULTS\APP7\ESCC.MDB

RTF Report Generation

C:\BR_TEX_RESULTS\APP7\ESCC.MDB


Print Auxiliary Scale (km)

Version

2.0.0.0 Appendix 7

EXIT Help

Report (p1) of AP7 (GIBC) program




**Rcv GSO ES (FSS) w.r.t.
Terrestrial St (TS, FS, MS)**

**Freq: 3850-4200 GHz
Sat longitude : 18 W
Horizon Ele. Anagle : 0**

Affected countries:

**Countries included
in Coordination
Distance/Area**



**Automatic
indication
in AP7 report**

<p>+</p> <p>ES position</p> <p>— Main Model 0.0db</p> <p>— Main Mode2 0.0deg</p>	<p>----- Aux. Model -5.0db</p> <p>----- Aux. Model -10.0db</p> <p>----- Aux. Model -15.0db</p> <p>----- Aux. Model -20.0db</p>	<p>----- Aux. Mode2 2.0deg</p> <p>----- Aux. Mode2 3.0deg</p> <p>----- Aux. Mode2 4.0deg</p> <p>----- Aux. Mode2 5.0deg</p>
--	--	---

Report (p2) of AP7 (GIBC) program

Diagram 4: 2.1_TABLE8. RECEIVING GSO ES in FIXED-SATELLITE SERVICE W.R.T. TRANSMITTING TERRESTRIAL STATIONS. TS in FS or MS

Example

GEO ID: 108500000 EARTH STATION NAME: BR SEMINAR ES1 EARTH STATION POSITION: 014E264035N5555E PHASE: N
 GEO AREA: BEL/MLT RAIN CLIMATICAL ZONE: K
 SATELLITE NAME: ITU BR TEST SAT SATELLITE ORBITAL POSITION: -18.00 DEG
 ANTENNA AZIMUT: 227.39 DEG ANTENNA ELEVATION: 36.00 DEG
 FREQUENCY BAND: 12.750 GHz BAND WIDTH: 36.00 MHz PERCENTAGE OF TIME: 0.0017 %
 MAXIMUM ANTENNA GAIN: 59.3 DBI MAXIMUM POWER DENSITY: - DBW/HZ NOISE TEMPERATURE: 100.0 K
 ANTENNA PATTERN: APEREC015V01
 2.1_TABLE8 Model: PLM_DUCTING

Tech parameters of the planning E/S

TRANSMISSION LOSS MODE 1: 204.9 DB (DOES NOT INCLUDE HOR. CORR. AND ANT. GAIN)
 TRANSMISSION LOSS MODE 2: 162.9 DB

AZIMUTH	0	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	105	110	115
OFF-AXIS	123.7	126.7	130.0	133.1	135.9	138.4	140.5	142.1	143.3	143.8	143.8	143.2	142.0	140.3	138.2	135.7	132.8	129.7	126.4	122.9	119.3	115.6	111.7	107.8
HOR. ELEV.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
HOR. CORR.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ANT. GAIN	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0
COORDINATION DISTANCE (KM)																								
MODE 1																								
0.0 DB	391	391	391	391	394	394	391	515	696	669	667	505	304	665	674	719	769	841	855	850	850	847	748	
MODE 2																								
0.0 DEG	321	321	321	321	321	321	321	321	321	321	321	321	321	321	321	321	321	321	321	321	322	322	322	322
AZIMUTH	120	125	130	135	140	145	150	155	160	165	170	175	180	185	190	195	200	205	210	215	220	225	230	235
OFF-AXIS	103.9	99.9	95.9	91.8	87.8	83.8	79.8	75.8	71.8	67.9	64.1	60.4	56.8	53.3	50.0	46.9	44.1	41.6	39.5	37.9	36.7	36.2	36.2	36.8
HOR. ELEV.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
HOR. CORR.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ANT. GAIN	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-9.8	-9.1	-8.5	-7.9	-7.5	-7.1	-7.0	-7.0	-7.1
COORDINATION DISTANCE (KM)																								
MODE 1																								
0.0 DB	703	691	765	801	820	808	674	626	618	595	561	465	425	301	302	408	427	374	470	470	477	491	488	485
MODE 2																								
0.0 DEG	322	322	323	323	323	323	323	323	324	324	324	324	324	324	324	325	325	325	325	325	325	325	325	325
AZIMUTH	240	245	250	255	260	265	270	275	280	285	290	295	300	305	310	315	320	325	330	335	340	345	350	355
OFF-AXIS	38.0	39.7	41.8	44.3	47.2	50.3	53.6	57.1	60.7	64.4	68.3	72.2	76.1	80.1	84.1	88.1	92.2	96.2	100.2	104.2	108.2	112.1	115.9	119.6
HOR. ELEV.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
HOR. CORR.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ANT. GAIN	-7.5	-8.0	-8.5	-9.2	-9.8	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0	-10.0
COORDINATION DISTANCE (KM)																								
MODE 1																								
0.0 DB	498	525	497	416	400	415	434	409	401	456	697	831	831	719	574	427	301	174	470	470	477	491	488	485
-10.0 DB	498	525	497	416	400	415	434	409	401	456	649	719	719	607	462	316	189	574	470	470	477	491	488	485
MODE 2																								
0.0 DEG	325	325	325	325	325	325	324	324	324	324	324	324	324	324	324	325	325	325	325	325	325	325	325	325

Calculated parameters by 5° Azimuth

Coordination distance by 5° Azimuth

(0 - 355°)

Probably Affected ADM in AP7 report

PROBABLY AFFECTED COUNTRIES: ALB GRC I LBY MLT TUN

How (Tx E/S)?

Azimuth x°

Coordination Distance

Max (Great-circle propagation (Mode 1) , Hydrometeor scatter (Mode 2))

$$L(\%) = P_t + G_e + G_x - P_r(\%)$$

ex: $G_x = 52$ dBi, $Pr(0.0025\%) = -98$ dBW/Hz for 12-14GHz

AP7 Table 7

$$L(\%) = P_t + G_x - P_r(\%) \quad (\text{Mode 2})$$

(Mode 1)

(Mode 2)


Great-circle propagation

Hydrometeor scatter


$P_t * G_e$

(10 to 123 Km/f) Minimum Coordination Distance

Maximum Calculation Distance (369/ Mode2 up to 1200 Km/ Mode1*Zone C)



Coordination area of **Tx GSO E/S (FSS)** with respect to **Rcv Terrestrial stations (FS)**



Freq: 5925 - 6425 GHz

Sat longitude : 1 W

Horizon Ele. Anagle : 0

Affected countries:

I LBY TUN

How (Rcv E/S)?

Azimuth x°

Coordination Distance

Max (Great-circle propagation (Mode 1) , Hydrometeor scatter (Mode 2))

$$L(\%) = P_t + G_e + G_x - P_r(\%)$$

ex: $G_x = 45$ dBi, $P_t = -3$ dBW, $p(0.0015\%)$ for 10-12.75GHz

AP7 Table 8

$P_t * G_x$

$$L(\%) = P_t + G_x - P_r(\%) \quad \text{(Mode 2)}$$

Hydrometeor scatter


Great-circle propagation

$P_r(p)$


G_e

(10 to 123 Km/f) Minimum Coordination Distance

Maximum Calculation Distance (369/ Mode2 up to 1200 Km/ Mode1*Zone C)



Coordination area of **Rcv GSO ES (FSS)** with respect to **Tx Terrestrial stations (FS)**



Freq: 3700 - 4200 GHz

Sat longitude : 1 W

Horizon Ele. Anagle : 0

Affected countries:

ALB GRC I LBY TUN

Contour of Opposite direction 1


MODE 1 Appendix 7 - Annex 3 & 5 + Table 9

Worst Case Scenario
(for Rx E/S)

- Horizon ele. angle (Rx E/S) = 0°
- Orbit inclination = 0°
- Anywhere in GSO orbit ($> \epsilon_{\min}$)
- Same latitude with Tx E/S

- Find Min. separation Angle of Rx E/S (for Azimuths)
- Calculate Distance with Off Axis Rx Gain

AP7 Table 9



Contour of Opposite direction 2

MODE 2

Appendix 7 - Annex 5 + Table 9


Worst Case Scenario +
(as Mode1)

- Plane geometry approximation
- Rx E/S operates at Min. Ele. angle
- Beam intersection under Rain height

Apply Geometrical construction

- Min. Coord. Distance (for some Azimuths)
- two 6° sectors => worst-case distance


No auxiliary contours (No calculation)



- h_R : rain height
- d_s : horizontal distance

- α_w : Azimuth to possible Rx E/S (by Latitudes, ϵ_{min})
- d_{emax} : Max calculation distance by h_R

Coordination area of Tx **GSO** ES (FSS) with respect to Rcv **GSO** ES (EESS)



Freq: 8025-8350 GHz


Sat longitude : 1 W

Horizon Ele. Anagle : 0

Affected countries:

I TUN

Coordination area of Tx **NGSO** ES (FSS) with respect to Rcv **GSO** ES (EESS)



Earth station (NGSO)

No Mode2 contours



Tracking Antenna reduce the probability of Mode2.

Main Mode 1

Aux. Mode 1

Coordination Area of Mobile Earth Stations

For a **mobile** earth station, the periphery of the service area is **extended by the coordination distance** (calculated or predetermined).



Predetermined Coordination distance

(Table 10 of Appendix 7)

||| Predetermined

AP7 Table 10




(Example Adm: KOR)

Typical, 100Km

Typical, 400Km

Typical, 500Km

Typical, 580Km




Typical, 1000Km

Typical, 1080Km

Specific, 100Km


Specific, 580Km





APPENDIX 7

Definition of the Coordination Area



45

Coordination contours with the greatest coordination distance

However

It represents a **regulatory concept** based on **Worst Cases & Conservative Assumptions.**

i.e.






It's **not** a **exclusion zone.**

means

More detailed calculations and discussions need to be performed.


Coordination data (Appendix 4)

Annex 2

	GEOGRAPHICAL DATA	(Earth station's) Location, Altitude
	SATELLITE	Orbital Location, Identification (Geo, Non-Geo)
	ANTENNA	Maximum gain Radiation pattern
	SIGNAL CHARACTERISTICS	Power Maximum Power Density Frequencies Noise temperature Emission Type
	Others	Horizontal Elevation Angle

Horizontal Elevation Angles


- All Azimuths around Earth Station Ant.
- if no values between → Average value
- **No values → default 0 degree**




Effect of Horizon Elevation Angle

RECEIVING EARTH STATION COORDINATION AREAS

MAGHTAB MLT/MLT 014E2640 35N5556 4135.0 - 4135.0 MHZ



HORIZON ELEVATION ANGLE : 0°



HORIZON ELEVATION ANGLE: Actual Value

Tips for Coordination ?

More practical consideration on the Coordination Area

AP7 embedded in GIBC

The screenshot shows the 'Graphical Interface for Batch Programs' window. At the top, there are tabs for 'Appendix 8', 'PFD (terrestrial serv.)', and 'PFD (space serv.)'. Below these are sub-tabs for 'Appendix 7', 'Appendix 30B', 'Appendix 30 30A', and 'Tools / Options'. The 'Network ID' field contains '109500000'. There are 'Calculate' and 'Report' buttons. Below are checkboxes for 'Warning', 'Error', and 'Progress', all of which are checked. A message log table is visible with columns 'Message', 'Module', and 'Code'. Under the 'Calculation Output' section, the 'Aux Contours' button is highlighted with a red box. Below this, the 'Out DB' path is 'C:\BR_TEX_RESULTS\APP7\ESCC.MDB'. The 'RTF Report Generation' section shows the same path and a 'Print Auxiliary' checkbox which is checked. The 'Scale (km)' field is empty. At the bottom, the 'Version' is '2.0.0.0' and 'Appendix 7'. 'EXIT' and 'Help' buttons are at the very bottom.

Auxiliary Contour

Extra coordination lines inside main contour

The dialog box 'Auxiliary and Supplementary Contours' has two columns: 'Mode 1 (dB)' and 'Mode 2 (deg)'. Each column has an 'Add' button and a list of values. Mode 1 values are -10.0, -15.0, and -5.0. Mode 2 values are 2.0, 3.0, and 5.0. There are 'Clear all' buttons for each column, 'OK', and 'Cancel' buttons on the right. A red box highlights the entire dialog content, and a red dashed arrow points from the 'Aux Contours' button in the main interface to this dialog.


It's all Complementary information.

Auxiliary Contour - Mode 1 (& 2)

Appendix 7 - Annex 6

Extra coordination lines
inside main contour
(decided between ADMs)

Country B



Coordination contour
($G_x = 50$ dBi)


- 10 dB Auxiliary contour
($G_x = -40$ dBW)

- 5 dB Auxiliary contour
($G_x = 45$ dBi)

Country A

Auxiliary Contour - Mode 1

Example



Auxiliary Contour
(ex. -5,-10,-15 dB)

MODE 2

Mode 1

Auxiliary Mode1

- 15.0 dB

- 10.0 dB

- 5.0 dB

Auxiliary Contour - Mode 2

Appendix 7 - Annex 6 (from WRC-2000)

Beam Avoidance Angle = X°

Main Mode 2

Protection Angle

Critical Angle


Earth Station

Auxiliary Mode2


Azimuth Y°

Azimuth Z°

Extra coordination lines
inside main contour
(decided between ADMs)



Auxiliary Contour - Mode 2



Main Mode2

Auxiliary Mode2


Avoidance angle 2.0°

Avoidance angle 3.0°

Avoidance angle 5.0°

Response by Administration B

(to Coordination Request from A)



Result of WRC-12

No major change in **AP7**

- **Some frequencies/services were deleted/added in Table 7 – 9.**
- **It's consequential arrangement with regards to Art 5 & footnotes.**

3 Things to Do
on **Coordination of Earth Stations**

1. Define Affected ADM (AP7)

2. Send Data (AP4 & AP7)

3. Do Coordination (with cooperation)